

Canon

WP-ONE (WP-310)	(IXUS) 100HS/115HS/220HS/230HS/310HS/430/500/700/750/800IS/900Ti/950IS/960IS/970IS/980IS/990IS (IXY) 500/600/700/800IS/810IS/820IS/830IS/1000/2000IS/3000IS (Powershot SD) 500/550/700IS/850IS/890IS/900/950IS/960/970/970IS/990IS (Powershot S) 90/100/110/410/500 (Powershot A) 480/490/495/800/1100/1200/3000IS/3100IS/3200IS/3300IS (Powershot) E1/ELPH 300HS
WP-ONE (WP-410)	(IXUS) 30/40/50/55/60/65/70/75/80IS/85IS/90IS/95IS/100IS/105/107/110IS/115HS/120IS/125HS/130/200IS/210/210is/230HS/240HS/300HS/330/400/500/500HS/510HS/850IS/860IS/870IS/1100HS/i7-zoom/i ii/i5-zoom/iis/v3/v2 (IXY) L/L2/L3/L4/10/20IS/25IS/30/30s/30a/50/55/60/70/80/90/95IS/110IS/200a/210IS/220IS/300a/320/400/450/510IS/900IS/910IS/920IS/930IS/wireless/10IS/400F/200F (Powershot SD) 10/20/30/40/100/110/200/300/400/430/450/600/630/750/770IS/780/780IS/790IS/800IS/870IS/940IS/960IS/980IS/1000/1100/1200IS/1300IS/1400IS/3500IS/4000IS (Powershot S) 200/230/330/400 (Powershot A) 2200/2300/2400/3200IS/3300IS/3400IS/4000IS
WP-510	(Powershot A) 60/70/75/80/85/95/420/430/450/460/470/495/510/520/530/540/550/560/570IS/580/590IS/710IS/800/1000IS/2000IS/2100/2100IS (Powershot S) 30/60/70/80
WP-710	(Powershot A) 100/200/300 D 10
WP-570	(Powershot) G7/G9/G10/G11/G15/SX100IS/SX110IS/SX120IS/SX160IS/SX200/SX200IS/210IS/SX220HS/SX230HS/SX240HS/A650 SD 4500IS/S95
WP-610	(Powershot) SX130IS/SX150IS/G11/G12
WP-H10	(Powershot) S3IS/S1IS/G6/G3/G2/G1X
WP-S5	DSLR (EOS) 20D/20Da/30D/40D/50D/60D/300D/350D/400D/450D/500D/550D/600D/650D/1000D/1100D (Powershot)S5IS/SX10IS/SX20IS/SX30IS/SX40IS/SX50HS
WP-S10	DSLR (EOS) 5D/5D MARK 2/5D MARK 3/6D/7D/10D/D30/D60/
	WP-S3 Hybrid (EOS) M

CASIO

WP-ONE (WP-110)	(Exilim) EX-Z 3/4/5/30/40/50/55/57/500/600/680/700/750/800/850/1000/1050/1080/1200SR EX-S 10/12/100/500/600/600D/770/880
WP-ONE (WP-310)	(Exilim) EX-Z 10/100/110/120/200/270/300/370/400/450/1200 EX-Z5 S 10/15/20/100/150 FC 100/200S H 5/10/15 FH 100/150 QV-R 3/4/40/41/51/61/100/1100 N 1/10 JE 10
WP-ONE (WP-410)	(Exilim) EX-Z 2/6/8/9/16/19/20/26/29/33/35/37/60/70/75/77/80/85/90/150/155/250/280/330/350/550/2000/2300/3000 EX-S 5/7/8/200 H 30 EX-ZR 20/150
WP-510	(Exilim) EX-P 600/700
WP-570	(Exilim) EX-ZR 10/100 EX-H 20G
WP-711	(Exilim) EX-M 1/2/20 EX-S 1/2/3/20 EX-V 7/8 EX-FS 10 G 1
WP-710	(Exilim) EX-TR 100(TRYX)
WP-H10	(Exilim) FS 20 P 505 FH 25

FUJIFILM

WP-ONE (WP-110)	(Finepix) F 440/450/455
WP-ONE (WP-310)	(Finepix) AX 200/230/280/300/350/355/ V 10 F 10/11/20/30/47/420/650 J 110W/150W/250 JZ 300/500 JX 200/250/280/300/305/350/500/520/580/700 F 31fd/40fd/45fd/47fd/50fd/60fd/70EXR/80EXR/72EXR/100fd/200fd/200EXR
WP-ONE (WP-410)	(Finepix) A 100/130/150/170/180/203/220/230/235/303/310/330/340/345/500/510/600/610/700/800/850 F 460/470/480 J 10/12/15/15fd/20/27/ 28/29/30/32/40/50 JV 100/110/150/200/205/210/1004 AV 100/110/130/150/200/205/250/255 S 4000
WP-510	(Finepix) E 500/510/550/900 A 610/820/900/920 T 200
WP-711	(Finepix) Z 1/2/3/5fd/10fd/20fd/Z100fd/Z200fd/300/Z300fd
WP-710	(Finepix) A 120/202 Z 30/33WP/35/37/70/80/90/110/700EXR/800EXR/900EXR/909EXR XP 10/22/30/33 REAL 3D W1
WP-570	(Finepix) F 300EXR/500EXR/550EXR/600EXR/660EXR/750EXR/800EXR JV 300 T 200/300/350/400 XF 1
WP-H10	(Finepix) S 1000fd/1500/1600/1700/1800/2000HD/2800z/2950/2990/4000/4500 X 10/100/PRO1 SL 280
WP-S10	DSLR (Finepix) S5 Pro IS Pro HS 20EXR/25EXR/30EXR
	WP-S3 Hybrid X E1/Pro 1

Panasonic

WP-ONE (WP-310)	(Lumix) DMC FX 100/150/700 ZR 1/3 ZX 1/3 FS 30/33/35/37 FH 20/22/25/27 LS 5
WP-ONE (WP-410)	(Lumix) DMC FX 1/2/3/5/7/8/9/10/12/30/33/35/36/37/38/40/48/50/55/60/65/66/68/70/75/77/78/90/180/500/520/550/580 FS 2/3/4/5/7/10/11/15/16/18/20/22/25 FH 1/2/3/5/6/7 F1 2/3/4/7 LS 1/2/70/80/85 LZ 8/10 S 1/2/3 S2 1
WP-510	(Lumix) DMC LZ 1/2 LC 50/70/80
WP-710	(Lumix) DMC TS 1/2/3/10 FP 1/2/3/5/7/8 FT 2/10 DMC 3D1
WP-570	(Lumix) DMC TZ 1/2/3/4/5/6/7/8/10/15/18/20/22/30 ZS 1/3/5/6/7/10/15/20 LZ 7 LX 1/2/3/5/7
WP-610	(Lumix) DMC GF1/GF2/GF3/GX1 (+14mm lens)
WP-H10	(Lumix) DMC GF2C FZ 5/35/38
WP-S5	DSLR DMC FZ 10/45 L 1/10 G 1/2/3/5/10 GH 1/2/3
	WP-S3 Hybrid DMC GF 1/2/3/5 GX 1

SAMSUNG

WP-ONE (WP-110)	(Kenox, Digimax) X60/X70/L70
WP-ONE (WP-310)	(Kenox, Digimax) V 3/4/5/6/10/20/700/800 A 4/5/6/7/40/50/400 D 4/5/6/7/103 S 85/800/830/100/1030/1060 Cyber 410/80 (VLUU) NV 8/10/15/20/24HD/25HD/100HD M 300w/310w BL 1050 ES 25/28/30/65/70/71/73/75/80 ST 45/65/70/71/500/550/600/5000/5500 SL 310/420/502/620/630/720/820 TL 34HD/210/220/225/240 IT 100 PL 55/60/65/70/80/90/200/210 CL 80 L 310w
WP-ONE (WP-410)	(Kenox, Digimax) U-CA 3/4/5 X 1/15wide/60 Q 1/2/25wide A 55W D 60/860 L 50/55W/60/73/74wide/700/730/830 S 500/600/630/700/730/760/830/860/1030/1070 (VLUU) NV 30/40/106HD/404 L 1/100/110/200/201/210/301 ES 10/15/17/20/55/60/90 SL 30/50/102/201/202 ST 30/35/40/50/60/66/77/80/90/93/95/96/102/ 202/600/700/710/6500 TL 90/100/205/320 PL 20/50/51/100/101/120/121/150/170/171 WB 1000/2000 SH 100 MV 800/900F DV 100/300F
WP-510	(Kenox, Digimax) 360/370/420/430/530 V 50/70 Cyber 300/400 α 5/7 L 85 X 85 D 60/370/430/470/510/530/610/3000/3100/4000
WP-711	(Kenox, Digimax) i5/i50mp3/i6/i6pmp/i7/i70/i8/i80/i85/i100 # 1/1mp3/11pmp K 50/60 D 512S (VLUU) NV 3/4/i8/i85/i7/i100 L 83T TL 9 T 10/1000 PL 10 CL 65
WP-710	(VLUU) NV i70/i80/9 L 77 ST 10/100/1000 WP 10
WP-570	(VLUU) WB 210/500/510/550/600(HZ30W)/650/700/850F (Kenox) S 1050/850 EX 1/2F
WP-610	(VLUU) NV 5/70ps/11 NX 100/200 WB 750
WP-S3	Hybrid NX 100/200/210/300/1000
	WP-S5 DSLR GX 1L/15/10/20 NX 5/10/11/20

PENTAX

WP-ONE (WP-110)	(Optio) S/S4/S4i/S5i/S5n/S5z/S6/S7/SV/Svi T 10/20/30 A 10/20/30/40
WP-ONE (WP-310)	(Optio) 30/50/60/330/430 A 36 S 40/45/50/55/60/330RS/430RS E 30/60 P 70/80 T 30 I 10 H 90
WP-ONE (WP-410)	(Optio) M 10/20/30/40/50/60/90 E 10/20/40/50/60/70/80/90 V 10/15/20 RS 1000/1500 NB 1000 L 70 LS 465/1000/1100 S 1
WP-510	(Optio) 33LF/33L/330GS/230/750Z S 30
WP-711	(Optio) WP/WPi/210/WS80 W 10/20/30/60
WP-710	(Optio) W 80/90
WP-570	(Optio) 750z RZ 10/18 VS 20
WP-610	(Optio) Q
WP-S5	DSLR K 5/7/10D/20D/30/100D/100D Super/110D/200D/R/X/ *ist D/DL/DS/DL2/DS2
	WP-S3 Hybrid Q/Q10/K-01



WP-ONE (WP-110)	(Coolpix) S 550/ 600/ 630/ 700/ 710
WP-ONE (WP-310)	(Coolpix) P 3/ 4 L 2/ 3/ 4/ 6 S 2500/ 2600/ 3100/ 3300/ 4100/ 4150/ 4300/ 6000/ 6100/ 6150/ 6200/ 6300/6400/ 8000/
WP-ONE (WP-410)	(Coolpix) 3700/ 4100/ 4600 S 01/200/ 203/ 210/ 220/ 230/ 500/ 510/ 520/ 560/ 570/ 610/ 610C/ 620/ 640/ 3000/ 4000/ 5100 L 10/ 11/ 12/ 14/ 15/ 16/ 18/ 19/ 20/ 21/ 22/ 23/ 24 P 300/310 => WP-ONE
WP-510	(Coolpix) 2200/ 3200/ 4200/ 5200/ 5600/ 5900/ 7600/ 7900 P 1/ 2/ 50/ 60/ 5000/ 5100 L 1 C 500ZOOM S 8100
WP-711	(Coolpix) S 1/ 2/ 3/ 5/ 6/ 7/ 7C/ 8/ 9/ 50/ 50C/ 51/ 51C/ 52/ 52C/ 60/ 70/ 80
WP-710	(Coolpix) S 100/ 1000pj/ 1100pj/ 1200pj/ 2500/ 3500
WP-570	(Coolpix) P 5000/ 5100/ 6000 S 8000/ 8100/ 8200/ 9100/ 9200 L 610
WP-610	(Coolpix) P 7000/ 7100/7700 1 J1/ V1
WP-H10	(Coolpix) P 80 L 100/ 110/ 120/810
WP-S5	DSLR D 40/ 40X/ 50/ 60/ 80/ 90/ 3000/ 3100/ 3200/5000/ 5100/ 5200/7000 F 6
WP-S10	DSLR D 70S/ 100/ 200/ 300/ 300S/ 500/ 700/800E
	WP-S3 Hybrid S1 J 1/2/3 V 1/2

OLYMPUS

WP-ONE (WP-110)	(Camedia) C 470z X 500/ 600 FE 150/ 160/ 5500 (u, Stylus) C 710/ 740/ 750/ 760/ 810/ 1000/ 1200/ D630z
WP-ONE (WP-310)	(Camedia) C 60z/ 370/ 480/ 500z X 1/ 2/ 3/ 350/ 450/ 550/ 825/ 840/ 845/ 855/ 880/ 935 FE 300/ 310/ 5000/ 5010/ 5020/ 5030/ 5035/ 5040/ 5050 VG 120/ 130/ 140/ 145/160/170 VH 210 (u, Stylus) C 1010/ 1020/ 1060/ 5000/ 5010/ 7000/ 7010/ 7020/ 7030/ 7040/ 7050/ 9000/ 9010 VR 320
WP-ONE (WP-410)	(Camedia) C 310z/ 315z X 775/ 785/ 790/ 815/ 820/ 875/ 895/ 920/ 930/ 940 VG 150 VR 320/330 FE 20/ 25/ 26/ 35/ 45/ 46/ 47/ 48/ 130/ 140/ 170/ 180/ 200/ 210/ 220/ 230/ 240/ 250/ 270/ 280/ 290/ 320/ 330/ 340/ 350/ 360/ 370/ 3000/ 3010/ 4000/ 4010/ 4020/ 4030/ 4040/ 4050 (u, Stylus) 10/ 15/ 20/ 25/ 30/ 40/ 40digital/ 300/ 400/ 500/ 600/ 700/ 780/ 800/ 820/ 830/ 840/ digital S/ Mini/ Verve S T 100/ 110
WP-510	(Camedia) C 1z/ 2/ 40 X 200/ 250 SP 320/ 350 (u, Stylus) 535/ 545/ 595z
WP-711	(u, Stylus) 700sw/ 720sw/ 725sw/ 730/ 795sw/ 850sw/ 1030sw/ 1040/ 1050sw/ 1070
WP-710	(Camedia) C 120/ 150/ 160/ 170/ 180 AZ 1 SP 700 IR 300/ 500 u 6010 Tough 3000/ 6000/ 6010/ 6020/ 8000/ 8010/ 550WP
WP-610	(Camedia) C 70z/ 700/ 730/ 740/ 745/ 750/ 755/ 760/ 770 PEN E-P1/ E-P2/ E-P3/ E-PL1/ E-PL2/ E-PL3/ E-PM1 (+17mm lenz) XZ 1 SZ 10/ 11/ 20/ 30MR
WP-H10	(Camedia) SP 590uz/ 570uz/ 565uz/ 560uz/ 550uz/ 510uz/ 500uz/ 600uz/ 610uz/ 810uz C 7070wz/ 5060wz/ 4000z/ 4040z/ 700uz/ 720uz/ 730uz
WP-S5	DSLR E 30/ 300/ 330/ 400/ 410/ 420/ 500/ 510/ 520/ 620/
	WP-570 SH 25 MR
WP-S10	DSLR E 1/ 3/ 5
	WP-S3 Hybrid E-PL 1/2/3/5 E-P 1/2/3 E-PM 1(Mini)/2 OM-D EM5

Kodak

WP-ONE (WP-110)	(Easyshare) V 530/ 550/ 803/ 1003/ 1073/ 1273
WP-ONE (WP-310)	(Easyshare) ONE/ JOC L108 LS 633/ 753/ 755 C 190/ 613/ 663/ 813/ 1013/ 1033/ 1093IS V 1233/ 1253 M 341/ 380/ 381/ 550/ 575/ 580/ 583/ 1033/ 1093IS/ 5370
WP-ONE (WP-410)	(Easyshare) C 142/ 143/ 180/ 182/ 183/ 195/ 533/ 643/ 653/ 743/ 763/ 913/ 1530 L 743 M 200/ 320/ 340/ 530/ 531/ 532/ 577/ 753/ 763/ 853/ 863/ 873/ 883/ 893IS/ 1063/ 1073IS/5350 MD 30 Mini
WP-510	(Easyshare) CX 6230/ 6330/ 7220/ 7330/ 7430/ 7530 DX 4330/ 4530/ 6340/ 6440/ 7440/ 7630 LS 443 Z 885/ 1275 C 330/ 340/ 360/ 875
WP-711	(Easyshare) M 590
	WP-710 (Easyshare) V 570/ 610/ 705/ silce
	WP-610 (Easyshare) Z 915/ 950/ 1285/ 1485IS
WP-H10	(Easyshare) 1012IS/ ZD710/ Z612/ Z650/ Z712IS/ Z710/ Z740/ Z812IS/ Z8612IS/ Z980/ Z981/ Z1015IS/ DX7590/ DX6490/ P712/ P850

SONY

WP-ONE (WP-110)	(Cybershot DSC) N 1/ 2 W 120/ 130 S 930/ 950/ 980
WP-ONE (WP-310)	(Cybershot DSC) P 100/ 120/ 150/ 200 W 100/ 570/ 580/670 S 800 WX 5/ 9/ 10
WP-ONE (WP-410)	(Cybershot DSC) S 40/ 500/ 600/ 650/ 700/ 750/ 780/ 2000/ 2100/ 3000 J 10 WX 1/ 7/30/ 50/ 70/100/150 W 30/ 35/ 40/ 50/ 55/ 70/ 80/ 85/ 90/ 110/ 150/ 170/ 180/ 190/ 200/ 220/ 230/ 290/ 300/ 310/ 320/ 330/ 350/ 360/ 370/ 380/ 390/ 510/ 520/ 530/ 550/ 560/ 610/ 620/630/ 650/690 HX 5
WP-510	(Cybershot DSC) P 1/ 2/ 5/ 7/ 8/ 9/ 10/ 71/ 72/ 73/ 92/ 93 W 1/ 5/ 7/ 12/ 15 S 60/ 90
WP-711	(Cybershot DSC) T 1/ 2/ 3/ 5/ 7/ 9/ 10/ 11/ 20/ 30/ 33/ 50/ 70/ 75/ 77/ 90/ 99/ 100/ 110/ 200/ 300/ 500/ 700/ 900 TX 1/ 5/ 7/ 9/ 10/20/ 55/66/ 100V/ 200V/ 300V
WP-710	(Cybershot DSC) U 10/ 20/ 30 P 31/ 32/ 51
WP-570	(Cybershot DSC) H 55/ 70 HX 5V/ 7V/ 9V/10V/30V RX 100
WP-610	(Cybershot DSC) H 3/ 10/ 20/ 30/ 50 V 1 NEX 3/ 5/ 7/ C3
WP-H10	(Cybershot DSC) H 5/ 7/ 9/50 V 3 HX 1/ 100V/200V
	WP-S3 Hybrid NEX 3/5/5R/5N/6/7/C3/F3 RX 1
WP-S5	DSLR alpha 33/ 35/ 37/55/ 57/ 65/ 77/99/ 100/ 200/ 230/ 300/ 350/ 380/ 390/ 450/ 500/ 550/ 560/ 580/ 700/ 850/ 900

SANYO

WP-ONE (WP-310)	(Xacti VPC) AZ3/ MZ31 E 7/ 10/ 875/ 1000
WP-ONE (WP-410)	(Xacti VPC) S 1/ 3/ 4/ 6/ 7/ 60/ 70/ 122/ 650/ 670/ 750/ 770/ 880/ 885/ 1080/ 1414 E 760/ 860/ 870G/ 890/ 1403/ 1500TP X 1200/ 1220/ 1420 T 700/ 850/ 1060/ 1495
WP-710	(Xacti VPC) J 1/ 2/ 4 DSC A5 / E6

KONICA MINOLTA

WP-ONE (WP-110)	(Dimage) E 500
	WP-711 (Dimage) X 1
WP-ONE (WP-310)	(Dimage) KD 200Z / 300Z / 510Z
	WP-710 (Dimage) X 20/ 21/ 31/ 50/ 60/ G/ i
WP-ONE (WP-410)	(Dimage) KD 400Z
	WP-S5 DSLR DYNAX 7D
WP-510	(Dimage) F 100/ 200/ 300 Revio KD 3300/4000Z

KYOCERA

WP-ONE (WP-310)	(Finecam) S3 (Yashica) EZ Digital 5030
	(Caprio) R21/ R1/ RR630/ RR660
WP-ONE (WP-410)	(Yashica) EZ Digital 5031
	(Caprio) RR770/ R50
WP-510	(Finecam) L 3 / 3V / 4 / 4V/ 30 S 3R/ 3L/ 3X/ 4/ 5/ 5R
	(Caprio) GR-D/ GR-DII/ GR-DIII/ GR-IV/ GX8/ GX/ RX/ G4wide / RR30
WP-710	(Contax) I 4R
	(Caprio) R40/ R10/ R8/ R7/ R6/ R5/ R4/ R3/ GX100/ GX200/ CX1/ CX2/ CX3/ CX4/ CX5/ CX6

RICOH

WP-ONE (WP-110)	Rollei Prego DP4200 BenQ DC E53 / 520 / 510 Hitachi imega HDC-531
WP-ONE (WP-310)	Minox DC8111 Rollei Prego DP8300 / 6300 / 5300/ DT3200 Mach power DX-550 Polaroid PDC3370 Praktica DC24.3 BenQ DC C40 / C50 Toshiba Alegretto 3310
WP-ONE (WP-410)	Toshiba Alegretto 3330 Hyundai DC-4300 Epson L-300 Leica C-Lux1/ Lux2/ Lux3
WP-510	Praktica DC24.4 Toshiba PDR5300 Premier DC2302 / 3306 / 5330 Kenko Z510 BenQ DC 5330 /S30 Kocom KDC-330 Hyundai HD-530 Hitachi imega HDC-331
WP-711	Che-ez Foxz2/ moni-me
WP-570	Leica Dlux3/ Dlux4/ Dlux5/ Dlux20/ X1 Sigma DP1/ DP1X/ DP2/ DP2X
WP-S5	DSLR Leica DIGILUX 3
	WP-610 Leica M9/ V-LUX30
WP-S10	DSLR Sigma SD14/ SD15/ SD1
	WP-H10 Leica V-LUX2/ V-LUX3